

MODEL # 6500

ASSEMBLY INSTRUCTIONS



HIGH-WHEEL CULTIVATOR

Congratulations on the purchase of your new EarthWay High-Wheel Cultivator.

Please contact us if you have any difficulty with assembly or operation of this product.

We can be reached at support@earthway.com or by calling 574-848-7491 Monday - Friday 8:00am - 4:30pm or visit us online at www.earthway.com

The 6500 comes with lifetime technical support.

HELPFUL HINTS

- ☑ The 6500 will require approximately 30 minutes to assemble with common hand tools.
- ☑ Remove and identify all loose parts from carton.
- ✓ Clean and dry your Cultivator thoroughly after each use.
- ☑ Coat all metal surfaces with a light oil to prevent corrosion.

CUSTOMER SERVICE

SUPPORT@EARTHWAY.COM | www.EARTHWAY.com | 1009 Maple Street, Bristol, IN 46507

ONE YEAR WARRANTY


EarthWay Products, Inc. warrants this product free of defects in original workmanship and materials for a period of one year to the end user with the original purchase receipt. If a manufacturing non-conformance is found, EarthWay Products, Inc. at its discretion will repair or replace the part(s)/product at no charge provided the failure is not the result of incorrect installation, mishandling, misuse, tampering, or normal wear and tear as determined by EarthWay.

EarthWay at its discretion may require that the part(s) or product be returned along with the original purchase receipt for examination and compliance with the terms of this warranty. Do not return any product without first receiving authorization from EarthWay Products, Inc.

To seek remedy under this warranty, contact EarthWay Products, Inc. at 574-848-7491, support@earthway.com or write to EarthWay Products, Inc. 1009 Maple Street, Bristol, IN 46507 and describe the nature of the manufacturing defect. SPECIFIC LIMITATIONS: This warranty covers only the part(s) or product; any labor charges associated with repair or replacement of non-conformances are specifically excluded. Due to the corrosive nature of most fertilizers and ice melt products, EarthWay Products, Inc. makes no warranty against and specifically excludes part(s) or product degradation or failure due to corrosion or its effects.




ASSEMBLY HARDWARE



ASSEMBLY INSTRUCTIONS

1. Assemble both (#4) Upper and (#3) Lower Handles together and secure with (#12) hex bolt & (#15) hex nut – do not tighten.

- 2. Assemble (#7) Left and (#6) Right Tool Supports, by positioning (#9) Tool Support Spacer between them at the end that has only one hole as shown in the exploded view, secure using (#11) hex bolt and (#15) hex nut and tighten. Make sure you have the Right and Left in the correct position as shown in the exploded view.
- Connect (#2) Frame to the Tool Support Assembly from step 2 using (#14) hex bolt thru the (#2) Frame and then



through both (#6 & #7) Tool Supports, then through (2) Frame on the other side and secure with (#16) lock nut, and tighten.

- 4. Install (#8) Cross Brace on to the Upper Handle and secure with (#10) hex bolt and (#16) lock nut to each side, loosely tighten.
- 5. Install (#5) Axle into (#23) Wheel and position between the (#2) Frame rails.
- 6. Now insert (#13) hex bolt through the hole in (#3) Lower Handle, (#2) Frame, then into (#5) Axle & (#23) Wheel, then (#2) Frame, (#3) Lower Handle and secure with (#17) Lock Washer & (#15) hex nut, and tighten.
- 7. Now determine a comfortable operation height and then remove (#15) hex nut and select one of the four adjustment holes in the top of (#6 & #7) Tool Supports and secure with (#15) hex nut and tighten.



ASSEMBLY OF TOOLS (see right)

FURROW PLOW


Place Furrow Plow in front of tool support slot. Put hex bolt (#19) through square hole in the plow and through slot in tool support. Next put formed washer (#20) over carriage bolt (#19) and tool support: fasten with lock nut (#18) and tighten fully.

HILLING / MOLD BOARD PLOW

Place Hilling Plow in position shown above. Put carriage bolt (#19) through square hole and through slot in tool support. Next put formed washer (#20) over hex bolt (#19) and tool support: fasten with lock nut (#18) and tighten fully.

MULTI-TINE ADJUSTABLE CULTIVATOR

Assemble Multi-Tine as pictured above. Put carriage bolt (#19) through rear of the mounting plate (#28) and through tool support and then the formed washer (#20) and fasten with lock nut (#18), tighten fully. Next, attach




the tines (#27) with bolt (#24) through flat washer (#25) and secure with hex nut (#26), leave loose until you determine tine width as required. Tighten fully.

6502 Optional Wood Handle Kit



| 6502 Parts List | | | | | |
|-----------------|--------------------|-----|--|--|--|
| KEY | DESCRIPTION | QTY | | | |
| Α | Left Tool Support | 1 | | | |
| В | Right Tool Support | 1 | | | |
| С | Wood Handle | 2 | | | |
| D | Hardware Package | 1 | | | |





Updated parts diagrams and ordering can be accomplished by visiting www.earthway.com

| KEY | QTY | DESCRIPTION | KEY | QTY | DESCRITION |
|-----|-----|--------------------------|-------|-----|-------------------------------|
| 1 | 2 | 1"ID X 4.5"IL BLACK GRIP | 17 | 1 | M8 LOCK WASHER ZINC |
| 2 | 2 | FRAME | 18 | 1 | M10 LOCKNUT |
| 3 | 2 | LOWER HANDLE | 19 | 1 | M10 X 50MM CARRIAGE BOLT ZINC |
| 4 | 2 | UPPER HANDLE | 20 | 1 | FORMED WASHER |
| 5 | 1 | AXLE | 21 | 1 | FURROW PLOW |
| 6 | 1 | RIGHT TOOL SUPPORT | 22 | 1 | HILLING (MOLDBOARD) PLOW |
| 7 | 1 | LEFT TOOL SUPPORT | 23 | 1 | WHEEL ASSEMBLY |
| 8 | 1 | CROSS BRACE | 24 | 5 | M8 X 25MM HHCS ZINC |
| 9 | 1 | TOOL SUPPORT SPACER | 25 | 5 | M8 FLAT WASHER ZINC |
| 10 | 2 | M6 X 40MM HHCS ZINC | 26 | 5 | M8 FLANGED HEX NUT ZINC |
| 11 | 1 | M8 X 30MM HHCS ZINC | 27 | 5 | CULTIVATOR TINE (5 REQUIRED) |
| 12 | 2 | M8 X 40MM HHCS ZINC | 28 | 1 | MOUNTING PLATE |
| 13 | 1 | M8 X 120MM HHCS ZINC | | | |
| 14 | 1 | M6 X 50MM HHCS ZINC | | | |
| 15 | 4 | M8 HEX NUT ZINC | | | |
| 16 | 3 | M6 LOCKNUT ZINC | | | |
| | | | 60132 | | OPTIONAL SLICING HOE ASSEMBLY |
| | | | 29 | 1 | SLICING HOE BLADE |
| | | | 30 | 1 | 1/4-20 X 3/4" HHMS ZINC |
| _ | | | 31 | 1 | SLICING HOE BRACKET |
| | | | 32 | 1 | 5/16-18 X 2" HX TAP BOLT ZINC |
| | | | 33 | 1 | TOOL ADAPTOR FOR SLICING HOE |